I39-210 Gigabit High Power PoE Injector

Quick Installation Guide

P/N: A625010400G

INTRODUCTION

Model	Description
I39-210	95W high power PoE output


PACKAGE CONTENTS

* 1x PoE injector
* 1x Quick Installation Guide

⚠ IMPORTANT:

1. Use CAT5 or 5e UTP/STP cables.
2. AC input (100~240V/AC, 50~60Hz,3A)

CONNECTION



Installation Steps:

1. Connect the included AC power cord to the injector. The Power LED (Yellow) should be lit.
2. Connect the Data IN port to a LAN switch using an Ethernet cable.
3. Connect the Power+Data OUT port to a powered device, i.e., IP camera, using another Ethernet cable. Make sure the PoE LED (Green) is lit.
4. Check if the powered device (IP camera) is working properly. An IP camera may take up to 1 or 2 minutes to power up.

All specifications are subject to change without noice.
Copyright © 2020 AETEK INC. All rights reserved.

AETEK INC.
3F, No.192, Lien-Cheng Rd., Chung-Ho, New Taipei City, 235, Taiwan, R.O.C.
| T: +886-2-82452822 | W: www.aetektec.com | E: sales@aetektec.com