


PACKAGE CONTENTS

* 1x PoE switch	* 1x Quick Installation Guide	* 1x M25 2 hole with screw kits
* 1x T25 L-wrench	* 1x Corrugated Tubing , 1x M25 screw plug, 1xM25 5 hole.	


⚠ IMPORTANT:

1. Install the PoE switch in a ventilated and dry place that is free of electromagnetic source, vibration, moisture, and dust.
2. Make sure the ventilation openings on the switch are not blocked.
3. Use CAT5 or 5e UTP/STP cables.
4. AC input (100~240V/AC, 50~60HZ) for a max. consumption of 120W.
5. IP67 rated housing.
6. Although housing is IP67 rating , this is not suitable for water jets.


CONNECTION




with Avigilon IRPTZ-MNT-WALL1 / MNT-PEND-WALL / WLMT-1001 / WLMT-1021 / WLMT-1031




with AXIS T91E61



with AXIS T91D61




with HANWHA SBP-300WMW1



IMPORTANT:

The cabinet must be grounded using a ground wire between the ground screw and earth ground.






LED DEFINITIONS

Power PW1/PW2	Green ON	Power is on and normal.
SFP port Green	Green ON	Fiber is aeeached.
	Green Flashing	Data is being transmitted / received.
LAN ports Green	Green ON	TX link is detected.
	Green Flashing	Data is being transmitted or received.
PoE ports Amber	Amber ON	PSE is activated and PD is detected.
	Amber OFF	PoE OFF

INSTALLATION

Use the included M8 hex socket screws to secure the power box to a pole-mount or corner mount bracket.

The mounting hole definition is illustrated below. The same mounting hole pattern apply to all pole-mount and corner-mount brackets.



ASSEMBLE CABLE GLANDS

