

# **Gigabit High Power PoE Injector Series**

# P/N: A625012502G

# **Quick Installation Guide**

Model	Description
136-210	Indoor 60W IEEE 802.3 bt PoE output
I36-210-V2	Indoor 60W IEEE 802.3 bt PoE output
139-210	Indoor 90W IEEE 802.3 bt PoE output
I39-210-V2	Indoor 90W IEEE 802.3 bt PoE output
146-210	Outdoor 60W IEEE 802.3 bt PoE output

Model	Description	
149-210	Outdoor 90W IEEE 802.3 bt PoE output	
149-211	Outdoor 90W IEEE 802.3 bt PoE output	
169-210	Industrial Gigabit 90W bt PoE output	
I69-210-V2	Industrial Gigabit 90W bt PoE output	
169-216	Industrial Gigabit 90W bt PoE output	
I69-216-V2	Industrial Gigabit 90W bt PoE output	

#### PACKAGE CONTENTS

* 1x PoE injector	* 1x AC power cord ( Indoor type only)
* 1x Quick Installation Guide	

#### CONNECTION

#### **Installation Steps:**


- 1. Connect the power cable to the injector. The Power LED (Green) should be lit.
- 2. Connect the Data IN port to a LAN switch using an Ethernet cable.
- 3. Connect the Power+Data OUT port to a powered device, i.e., IP camera, using another Ethernet cable. Make sure the PoF LFD is lift.
- 4. Check if the powered device (IP camera) is working properly. An IP camera may take up to 1 or 2 minutes to power up.

# **LED** definitions

Power	Green ON: power good; OFF: power failed.
PoE	Amber ON: PD datected

# **Application**


# I36-210 / I36-210-V2 / 39-210 / I39-210-V2



### 169-210 / 169-210-V2 / 169-216 / 169-216-V2


#### Input Power:

169-210 / 169-210-V2: 48~56VDC for 802.3 at / af 52~56VDC for 802.3 bt




#### Application


# 146-210 / 149-210 / 149-211




Route your power wires through a 3/4" conduit into the power box. The wiring scheme is shown below. The power supply converts 100~240V power to the 95W PoE output to IP cameras.



Use the included M8 hex socket screws to secure the power box to a pole-mount or corner mount bracket.




The mounting hole definition is illustrated below. The same mounting hole pattern apply to all pole-mount and corner-mount brackets.




#### AC Power Cable Spec.


Wire Size	10~18AWG
Wire Strip Length	8mm



The power box can be mounted with the AT-100,AT-101 pole-mount, AT-200 corner-mount bracket, or directly secured to a wall. (I49-211 Only)



If the power box is directly mounted to wall, drill holes in a diameter of 9.5mm or 3/8", and 4cm deep. (I49-211 Only)



Use the following mounting positions for the camera housings (via BK-101 brackets). (I49-211 Only)

